



Electrical installation Remote Control Jet Thruster Single

Option A: Connection to Joystick unit:

Cable 1 Primary side joystick (+12V)

Cable 2 A

Cable 3 B

Cable Yellow/Green Ground

(Interchange **A and B** to invert the direction of the thrust output)

Option B: Connection to Pump unit:

Connect to marked screw connectors:

Cable 1 +

Cable 2 A

Cable 3 B

Cable Yellow/Green G

(Interchange **A and B** to invert the direction of the thrust output)